

## Replacing ProOne® G2.0 C1 Filters for Kohler Clarity

### When should I change my filters?

Recommended replacement is once every 6 months.


If you notice a difference in the taste/smell of your water and/or a slowdown in the flow rate, this may indicate your filters need to be cleaned. If after cleaning, the flow rate does not increase or you still notice the same taste/smell, it may be time for replacement.

### Cleaning the Filter

It is important to not allow water to leak into the blue stem of the plastic base. Hold filters by the base and place under cool running water for about 2 minutes. While continuously running under water, scrub the white ceramic material with the abrasive side of included sponge. Rinse well and lay on side until ready to install. Do NOT use soap on the filter. Do NOT allow water to enter the stem of the filter.

### Installing the Filter

1. Take (a) filter and place (b) black rubber washer onto stem.
2. Insert filter stem through hole in upper container.
3. Place (c) white nylon washer on underside of upper container.
4. Screw (d) wing nut onto threaded stem. Do NOT overtighten.



\* We recommend you discard the first 2 cycles before using.